


CHIEF
STATIEDIENST
VHR

H. ind
0
V. ind
0
V. ud
H. ud
14V.~



2 H. ind-Right-in-Entrée droite-Rechts ein
V. ind-Left-in-Entrée gauche-Links ein
H. ud-Right out-Sortie droite-Rechts aus
V. ud-Left out-Sortie gauche-Links aus


rod - red - rouge - rot
blå - blue - bleu - blau
brun - brown - brun - braun
gul - yellow - jaune - gelb
sort - black - noir - schwarz
hvid - white - blanc - weiss
grøn - green - vert - grün
motor - motor - moteur - Motor

- | | | |
|-----------------------------------|---|---|
| Kortslutningsstykke | { | Shortcircuit plate
Plaquette de court-circuit
Kopplungsplatte |
| 8-7506
Stikprop set
mod ben | { | Plug seen against contact-pins
Pricc de courant vu contre le baton
Stecker gegen Kontaktstäbe gesehen |
| P. U. enhed
set mod ben | { | Cartridge seen against contact-pins
Tête de pick-up vu contre le baton
Tonabnehmer gegen Kontaktstäbe gesehen |




STEREO
PLADESPILLER
RECORD-PLAYER
TURNE DISQUE
PLATTENSPIELER

Met dank aan Peter Spies Type: 5202 og 5203



1630830
0630830



8005000
Kortslutnings-
stykke

0530514

PU ENHED
SET MOD BEN.

DIN 8-7506
STIKPROP SET
MOD BEN.

0680693

Met dank aan Peter Spies

R