


EF80 ECH81 EF93 EA11 EM11 EL61

ZF = 450kHz u. 10,7MHz

Drehschalter	Zugschalter
Bereich	1 2 3 7 9 16 18 20 21 23 27 30 31 33 34 35 37 38 40 42 44 45 46
UKW	2 3 4 8 10 15 16 22 23 26 27 28 29 32 33 34 35 36 37 38 39 40 41 43 44 45 46
Lang	
Mittel	
Kurz	
IA	

50/51 stark normal



Sochetschaltungen