



ZF = 130 KHZ

Schalter Nr.	1	2	3	4	5	6
Lang						●
Mittel	●					
Pic-up						●

BIENNOPHONE 264, 462

Stabo-Bel.