








Met dank aan John Koster

Belastbaarheid / Rating



Schallerdiagramm
Switch diagram



Gezeichnete Schallerstellung : FM
 Switch shown in position : FM
 Kontakt contact
 Leerkontakt no contact
 o not wired

Lido 22500