



Schalter	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
U	X																	
K		X																
M			X															
L				X														
TA					X													



EF42/ECH42
EBF15, ECL11
EM11, AZ11
Sockelschaltungen

ZF = 468 kHz u. 10,7 MHz

Mefinstrument: 833 Ω / V

Emud 661

65W

