



	A	B	C	D	E	F	G	H	J	K	L	M	N	O	P	
1	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	LW
2	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	ANT
3	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	MFV
4	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	KW
5	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	UKW
6	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	UKW

Service-Schaltbild  
 GRAETZ-UKW-Transistor-Koffer- und Autoempfänger  
 „Joker“ 1034

„Joker“ 1034

„Joker“ 1034

„Joker“ 1034

„Joker“ 1034

„Joker“ 1034

„Joker“ 1034