



Buchse
SOCKET
Prise

Netz
MAINS
Secteur

SOCKET
Prise

9N sw / bl
GRN BLK / BL
vert noir / bleu

RD rouge

Ausgangstrafo
OUTPUT TRANSFORMER
Transfo de sortie

210V
215V

218V
228V

1,35V
1,4V

143V
146V

95V
96V

1,15V
1,2V

147V
150V

225V
229V

238V
242V

233V
237V

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k

10M
10k