



A70



The A70 Receiver

Although the cord drive for this receiver looks a rather elaborate affair, it is one of the simplest to fit. Fifty



inches of cord are required. To make the drive most accessible, turn the drive wheel fully anti-clockwise. The cord is placed round the guide wheel and fastened. Then the tension spring is fitted over the fixing lug; finally, the pointer is fitted on the cord to register with the top markings on the tuning scale.