



S	50.52.54.5674.89.17.	16.	58.	55.56.57.10.11.	59.60.	28.	12.14.13.15.	18
C	80.	9.81.82.253.83.5.	52.85.94.54.95.90.91.13.15.14.21.87.92.93.50.6.17.11.88.16.18.51.24.26.	19.27.	27.7.18.25.23.12.	30.31.	23.33.	
R	60.	35.61.62.	38.63.3.	4.	14.	7.6.	5.11.	9.10.8.




EABC80

EL84

EZ80



SK 7 }
 SK 8 } COMMANDES TOTALE
 SK 10 }
 SK 11 } TOONCHAKELAAR



Récepteur RADIO Ontvanger

SBR R17

DAT: 29-9-61 R-W-R17-2

