



PRINCIPESCHEMA.




SPORLEN	BEREKENK.	CONDENSATOREN	BEREKENK.	WIERSTANDEN	BEREKENK.		
S1 = 3300 W	A 15021	C1 = 3 μF.	C10032	R1 = 0,1 M.Ohm.	W 10177		
S2 = 3300 "		C2 = 1 "		R2 = 95 Ohm.		W 10176	
S3 = 3000 "		A 32003		C3 = 90000 om.		R3 = 220 "	W 10178
S4 = 3000 "				C4 = 4 μF.		R4 = 2 "	
S5 = 44 "		A 10165		C5 = 1 "		R5 = 165 "	W 10178
S6 = 44 "				C6 = 2 "		R6 = 165 "	
S7 = 224 "		A 10166		C7 = 250 om.		R7 = 0,6 k.	W 10100
S8 = 57 "		A 10179		C8 = 60 om.		R8 = 15000 Ohm.	
S9 = 149 "		A 10171		C9 = 15 om.		R9 = 57+57+171 "	W 10176
S10 = 2 x 35 "		A 10172		C10 = 750 om.		R10 = 1000 Ohm.	W 10179
S11 = 4000 "		A 32000		C11 = 750 om.		R11 = 0,6 M.Ohm.	
S12 = 12000 "	C12 = 150 om.		R12 = 350 Ohm.				
LAMPEN		C13 = 1000 om.	C10001	R13 = 200 "	W 10179		
L1 : B 442		C14 = 80000 om.	C10002	R14 = 200 "			
L2 : B 415		C15 = 1 μF.	C10027	R15 = 350 "	W 10179		
L3 : B 543		C16 = 20000 om.	C10029				
L4 : 1904			C10057				

BYBEH. SCHEMA'S		SPANNING (In Volt)		1 en 2 doorverbinden 2 en 3 " niets "
		Nom.	Grenzen	
Condensatordeus C 1,2,4,5,6,15	S10122	200	190 - 210	
Laagfreq. en Output transf. S 10,11,3,4.	S10012III	220	210 - 230	
Condensatordeus C3	S10008	240	230 - 250	
Spoolenset 55, 56,7	S10171			
58,9,10	S10171			
Condensatordeus C16	S10175			

Ned. Ver. v. Historie v/d Radio



MONTAGESCHEMA.



Spaming in Volt		Verbindo	
Nono	Grenzen	Verbindo	geen.
200	190-210	1-2	
220	210-230	2-3	
240	230-250		geen.

RF voedings afregelen. (doorverb. tusschen punten 78-79-80-81) dat span. op lamp. H. t. z. o. d. i. o. n. t. moge lyk by 60 amp. H. t. z. o. d. i. o. n. t.

